

Panasonic

ALCALINAS



1350

PILHA ALCALINA AA
LV 4 PG 3 PANASONIC

7896067204023



1351

PILHA ALCALINA AAA
LV 4 PG 3 PANASONIC

7896067204030



1354

PILHA ALCALINA PALITO C/6
SM PANASONIC "AAA"

7896067203675



1360

PILHA ALCALINA BATERIA 9
VOLTS C/ 1 SM PANASONIC

7896067203460



1361

PILHA ALCALINA PALITO
C/ 2 CT PANASONIC "AAA"

7896067202401



1362

PILHA ALCALINA PALITO
C/ 2 SM PANASONIC "AAA"

7896067200186



1363

PILHA ALCALINA PALITO
C/ 4 SM PANASONIC "AAA"

7896067201398



1365

PILHA ALCALINA MÉDIA
C/ 2 SM PANASONIC "C"

7896067200155



1370

PILHA ALCALINA PEQUENA
C/ 2 CT PANASONIC "AA"

7896067202395



1371

PILHA ALCALINA PEQUENA
C/ 2 SM PANASONIC "AA"

7896067200162



1372

PILHA ALCALINA PEQUENA
C/ 4 SM PANASONIC "AA"

7896067200179



1374

PILHA ALCALINA PEQUENA
C/ 6 SM PANASONIC "AA"

7896067203002

Panasonic

PREMIUM



1311

PILHA ALCALINA PREMIUM
AAA C/2 PANASONIC

7896067203743



1312

PILHA ALCALINA PREMIUM
AAA C/4 PANASONIC

7896067203750



1313

PILHA ALCALINA PREMIUM
AAA C/6 PANASONIC

7896067203767



1314

PILHA ALCALINA PREMIUM
AA C/2 PANASONIC

7896067203712



1315

PILHA ALCALINA PREMIUM
AA C/4 PANASONIC

7896067203729



1316

PILHA ALCALINA PREMIUM
AA C/6 PANASONIC

7896067203736



1317

PILHA ALCALINA PREMIUM
AA LV 4 PG 3 PANASONIC

7896067203897



1318

PILHA ALCALINA PREMIUM
AAA LV 4 PG 3 PANASONIC

7896067203903



1319

PILHA ALCALINA PREMIUM
AA CT C/2 PANASONIC

7896067203835



1320

PILHA ALCALINA PREMIUM
AAA CT C/2 PANASONIC

7896067203859



1402

PILHA ALCALINA
PREMIUM AA LBP6

7896067204115



1404

PILHA ALCALINA
PREMIUM AAA L8 P6

7896067204139

Panasonic

COMUM



1358

PILHA COMUM PEQUENA C/
4 TUBO PANASONIC "AA"

7896067203880



1380

PILHA COMUM PALITO C/
4 SM PANASONIC "AAA"

7896067203033



1381

PILHA COMUM PALITO C/
4 TUBO PANASONIC "AAA"

7896067203040



1382

PILHA COMUM PALITO C/
8 SM PANASONIC "AAA"

7896067203125



1384

PILHA COMUM GRANDE
C/2 SM PANASONIC "D"

7896067200018



1385

PILHA COMUM MÉDIA C/
2 TUBO PANASONIC "C"

7896067200346



1386

PILHA COMUM MÉDIA
C/2 SM PANASONIC "C"

7896067200025



1388

PILHA COMUM PEQUENA
C/4 SM PANASONIC "AA"

7896067200032



1389

PILHA COMUM PEQUENA
C/8 SM PANASONIC "AA"

7896067202982

Scapol

Panasonic

BATERIAS



1310

BATERIA DE LITHIUM 2032
MOEDA PANASONIC

7896067203958



1375

BATERIA AUDITIVA
C/6 PR 13 PANASONIC

7896067200278



1376

BATERIA AUDITIVA C/
6 PR 230 PANASONIC

7896067200292



1377

BATERIA AUDITIVA C/
6 PR 312 PANASONIC

7896067200285



1378

BATERIA AUDITIVA C/
6 PR 675 PANASONIC

7896067200261



1390

BATERIA LITHIUM 2016
BOTÃO C/ 5 PANASONIC

7896067202326



1391

BATERIA LITHIUM 2025
BOTÃO C/ 5 PANASONIC

7896067202364



1392

BATERIA LITHIUM 2032
BOTÃO C/ 5 PANASONIC

7896067202340



1393

BATERIA ALCALINA ALARME
12V C/ 1 SM PANASONIC

7896067200551



1394

BATERIA ALCALINA ALARME
12V C/ 1 CT PANASONIC

7896067203491